



WELD ALL THE WAY AROUND ROTATOR RAIL

HANDLE PIN HOLE MUST BE ALIGNED WITH ONE OF THE FLANGE LOCK HOLES PRIOR TO WELDING ROTATOR RAIL TO HANDLE BARREL.

INSTALL ROTATOR RAIL ROUND SIDE DOWN